



DN-201-5P-UP to DN-201-8P-UP



DN-201-4P-UP



ARRANGEMENT OF CONTACTS					
NO OF CONTACTS	4	5	6	7	8
MODEL NO	DN-201-4P-UP	DN-201-5P-UP	DN-201-6P-UP	DN-201-7P-UP	DN-201-8P-UP